


Video Instruction

(Click on Image below to start play video or right click to play on larger format)



iDRAC6 Configuration Upon powering up your Sentrion, follow these steps to run the iDRAC6 configuration utility for adding iDRAC6 support:

1. From the command line, press **Ctrl-E** to access the configuration utility and begin the Remote Access Setup. This should be done after the RAID check during the power-on self test (POST) , but before the operating system loads. If the operating system begins to load before you press **Ctrl-E**, allow the system to finish loading before restarting.